



Kellfri[®]

ADJUSTABLE PALLET FORK

16-JPFE15 16-JPFT15

16-JPFE25 16-JPFT25



**READ THIS MANUAL CAREFULLY BEFORE USING THE PRODUCT !!!
TRANSLATED FROM THE ORIGINAL**

INTRODUCTION

Thank you for choosing a product from Kellfri AB. By following general safety information, operating instructions and common sense, you will have many years of enjoyable use of the product. Kellfris equipment and products are aimed to be use by active farmers with high demands on functionality.

PRODUCT INFORMATION

Adjustable pallet fork with strong frame. Forged forks with wide load bearing surfaces which distribute the load across a wide area. A stable pallet fork supplied with Trima or Euro attachments. (not 16JPFES that only comes with Euro attachment).

APPLICATION AREA

Intended for handling of pallets.

TECHNICAL DATA	16-JPFE15	16-JPFT15	16-JPFE25	16-JPFT25
Pallet fork length	1000 mm	1000 mm	1200 mm	1200 mm
Pallet fork width	120 mm	120 mm	120 mm	120 mm
Pallet fork thickness	40 mm	40 mm	40 mm	40 mm
Pallet fork frame width	1220 mm	1220 mm	1220 mm	1220 mm
Pallet fork frame height	690 mm	690 mm	690 mm	690 mm
Max load	1500 kg	1500 kg	2500 kg	2500 kg
Weight	190 kg	178 kg	202 kg	190 kg

Kellfri disclaim any responsibility for self-made modifications, changes or alterations


BASIC SAFETY INSTRUCTIONS

Before using the equipment or product, and for the safety of yourself and others, you must read the safety instructions and the instruction manual and understand its contents, Always keep the safety instructions and instruction manual handy for users of the equipment or product. For the safety of both yourself and others, it may be a good idea to read through the safety instructions every now and then. If the safety instructions or instruction manual gets damaged or in any other way cannot be used, new copies may be ordered from:

Kellfri AB, Munkatorpsgatan 6, 532 37 SKARA

Sweden. Tel.: +46 (0)511 242 50 (Pls. contact the retailer) <https://www.kellfri.co.uk/>

Do not use the equipment or product if you feel ill, tired or are under the influence of alcohol. Do not use the equipment or product if you are taking prescribed medication or drugs. Always comply with general rules of the road and applicable rules stipulated by the Swedish Protection of Animals Act. People under the age of 15 are not allowed to use the equipment.



PRODUCT SAFETY INFORMATION

- Read the Instruction Manual carefully before using the machine.
- Always check the equipment and machine combination that will be used to ensure the safety and function.
- Check that the equipment is not damaged before use.
- Make sure that the equipment is correctly attached and won't come loose. Always check the locking pins before use.
- Only the operator is allowed in the vicinity of the machine during operation.
- Never overload the cart.
- Nobody is allowed to stay under suspended load.
- Never leave the tractor before the equipment is unloaded and the tractor braked.

INSTRUCTION FOR EMERGENCIES

In case of an emergency please dial 112.

Keep cell phone or emergency phone available specially when working alone. First aid kit and fire extinguishers must be kept easily accesable during all work, maintenance and service.To perform an emergency stop, turn off the tractor.

PERSONAL PROTECTIVE EQUIPMENT

Wear suitable clothing and footwear. Do not wear loose clothing or jewelry when working with the equipment. Remember to put up long hair when working with equipment that rotates.



WARNING LABELS

Make sure that the warning decals are always visible, clean the warning labels if necessary. Do not wash with high pressure washer directly on the warning label. If any part of the decal is worn or label becomes frayed or otherwise unreadable, order new decals.

SYMBOL

EXPLANATION



Warning! Suspended load

Riskzon 5 m

Warning! Danger zone



The equipment is CE marked

SURROUNDINGS

Check and make sure that the area is clear of people, children and objects before switching on or using the equipment. Risk of serious personal injury. Be especially careful if children are in the area where the equipment is being use or stored. Check that there are no low-hanging power lines within the work area. Be careful when working on slopes and near ditches. Always work alone with equipment designed for single - purpose tools/products. Never have junk/ debris lying in your work area. Have workspaces clean. Always respect the risk zone.



BEFORE USING

Read the safety information and operating instructions carefully. Be sure that you understand the safety information, operating instructions and warning labels. Use common sense when using the machine and use appropriate personal protective equipment Always check the performance and the machine combination that are use. It's highly important these matches in a satisfactory manner. This is to ensure the product or the function and most important yours and others safety. Do visual inspection of equipment or product before use. Fix or replace damaged or worn parts immediately to reduce the risk of injury. Lubricate moving parts and check that all screw-nuts and bolts are tightened.

Learn and remember the correct working methods. Beginners should always keep a low speed, use extreme caution before routine and product knowledge is achieved. The user/customer is responsible to handle the situation correctly. The product should not be taken into use unless it can be done in a safe way for the user.



SWITCHING ON AND SWITCHING GEAR

- The gear is mounted on the tractor's front loader and secured with locking pins.
- Make sure the tool is properly assembled before use.



USE / OPERATION

Only people who understand the safety information and instructions in this manual may operate the equipment. Be alert and careful when working with the machine and only use the tool or product in the manner described in this manual. Avoid the use of the tool at lower temperatures than -20°C and higher temperatures than $+30^{\circ}\text{C}$.

Always work alone with the tools that are defined as single purpose tools. Respect the equipment's danger zone.

TRANSPORT AND STORING

Make sure there are no people, children and foreign objects around the area before transporting the machine. Always take an extra caution during the transport. Ensure that the product is well secured and that transport brackets are mounted. Always place the load as low as possible. Respect the danger zone even during transport. When lifting the equipment, never go underneath suspended loads. Trailer used for transport should have working brakes.

Always store the machine in a dry place preferably underneath a cover when not in use. Ensure that the product is stable and not likely to tip over. Never let children play where the machine is being stored. Always keep in mind the risk of tipping!

MAINTENANCE AND SERVICE

Ensure that the unit is stable and cannot tip over during maintenance and service. Replace damaged or worn parts immediately to reduce the risk of abrasion. Always perform maintenance, service and inspection, as recommended. Use only original replacement parts or spare parts with equivalent performance to reduce the risk of damage.

Check all nuts and bolts are tightened after performing maintenance and service.

RECYCLING

Disposal of the product, disassemble and transport to the municipality's recycling station. Contact your local authority for further information.

We are grateful for your help pointing out any inaccuracies in the Kellfri product delivered to you. Before making a complaint read Kellfris general warranty and sales conditions in our catalog as well as the enclosed User's manual that comes with the machine.

Please fill in the details below and attach photo and other information in order to process your request.

Buyer:	Customer number:
Adress:	Invoice number:
E-mail:	Phone nr:

When was the product delivered?	When was the product taken into operation?	Did the product functioned as it should upon the first operation?
--	---	--

Defect product / part:

Problem description:

Describe the sequence of events:

Other:

Submit Complaint form and photo to:

Kellfri AB

Division of Services : Contact Kellfri retailer

Munkatorpsgatan 6

532 37 Skara

Or e-mail service.

info@kellfri.se

Signature:	Date:
-------------------	--------------

KELLFRI AB
Munkatorpsgatan 6
SE-532 37 SKARA
Phone: +46 (0)511-242 50
Fax: +46 (0)511-168 33

Web
www.kellfri.se
E-mail
info@kellfri.se
Issue:: 2014-01-01

WARRANTY TERMS AND CONDITIONS

- Validity of the warranty - Kelifri's Warranty is valid 12 months from the date of purchase
- This warranty replaces - Compensation for spare parts after acknowledgment that the fault lies on the material or manufacturing defects.
- This guarantee do not cover
- Labour costs
 - Travel expenses
 - Any modification that the buyer himself has/had made.
 - Any consequential damages that occurred out of damage to the machine.
 - Damage due to normal deterioration of the machine, inadequate: service, user inexperience or use of spare parts which are not original.
 - Wear parts such as hoses, seals, oils, and mechanical belts

EG-FÖRSÄKRAN OM MASKINENS ÖVERENSTÄMMELSE, ORIGINAL

EC-DECLARATION OF CONFORMITY

According to 2006/42/EC, Annex 2A

Kelifri AB

Munkatorpsgatan 6

532 37 Skara, Sweden

Declares that the machine

Name: 16-JPFE15, 16-JPFT15, 16-JPFE25, 16JPFET25

Type: Adjustable pallet fork

Complies with all applicable provisions of the General product safety Directive 2001/95/EC

Other equipment must meet the safety requirements of the Directive.



Tina Baudtler, VD 2015-09-15

Kelifri AB is constantly working on further developing their products and therefore reserves the right to modify, among other things the design and appearance without notice

CUSTOMER SERVICE

You are always welcome to give your feedbacks, reviews or ask us about our tools and products.

KELFRI AB

Phone : 0046 (0) 511 - 242 50

Fax: 0046 (0)511 - 168 33

E-mail : info@kelifri.se



Kelifri®